





ACCESSORIES	
Fixture can only be used with following optical accessories.	
CHARLATAN Ø65	- 10210001 Reflector Ø65 LED spot - 10210002 Reflector Ø65 LED medium - 10210003 Reflector Ø65 LED flood
CHARLATAN Ø85	- 10210004 Reflector Ø85 LED spot - 10210005 Reflector Ø85 LED medium - 10210006 Reflector Ø85 LED flood
CHARLATAN Ø100	- 10210007 Reflector Ø100 LED spot - 10210008 Reflector Ø100 LED medium - 10210009 Reflector Ø100 LED flood



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Always be properly grounded when touching leads or circuitry inside the luminaire. Use a wrist strap connected by a ground cord to the housing. Avoid touching the light sources with bare hands.











